

Vehicle make :	TOYOTA PPTOY25.2
Engine type :	Prado D4D
Cautions :	Tune Fuel with Joined Pots
ECU location :	Behind Glove Box
Special Notes :	TPS on 0-5v1. Water Temp on 0-5v2
Unichip version :	Q4

Map

Function

TIMING 1 = Injection Timing +/- 6 degrees

FUEL 1 = Fuel Rail Pressure +/- 50

TPS = Fuel Rail Pressure +/- 50

Map values must
be identical

OPTION 1 / Fuel 2 = Boost Map +/- 50

OPTION 2 = Not Used

OPTION 3 = Not Used

OPTION 4 = Not Used

OPTION 5 = Not Used

OVERDRIVE = Not Used

TARGET BOOST = Not Used